

Slugging Wrench

What is a slugging wrench used for?

Hammer wrenches, striking wrenches, and slugging wrenches are commonly used for **loosening and tightening nuts and bolts in refineries, pipelines, chemical plants, flanges, and other areas.**

TYPES OF SLUGGING WRENCHES



- **Straight Ring Type**



- **Offset Handle Type**
- **Open Jaw Type**
- **Podgier / Tommy Spanners**
- **Box Ring Type**
- **Square Drive Type Slugging Wrenches**

Open Type Spanner

Part No	Spanner Size A/F		Open Spanner		
	MM	Inch	Head Dia	Head Depth	Length
HOP-32	32	1-1/4"	78	17	208
HOP-33	33	1-5/16"	78	17	208
HOP-35	35	1-3/8"	78	17	208
HOP-36	36	1-7/16"	78	17	208
HOP-38	38	1-1/2"	78	17	208
HOP-41	41	1-5/8"	108	19	274
HOP-43	43	1-11/16"	108	19	274
HOP-44	44	1-3/4"	108	19	274
HOP-46	46	1-13/16"	108	19	274
HOP-47	47	1-7/8"	108	19	274
HOP-50	50	2"	108	21	274
HOP-52	52	2-1/16"	108	21	274
HOP-55	55	2-3/16"	108	21	274
HOP-57	57	2-1/4"	108	21	274
HO -60	60	2-3/8"	108	21	274
HOP-62	62	2-7/16"	148	31	360
HOP-63	63	2-1/2"	148	31	360
HOP-65	65	2-9/16"	148	31	360
HOP-67	67	2-5/8"	148	31	360
HOP-70	70	2-3/4"	148	31	360
HOP-71	71	2-13/16"	162	31	398
HOP-75	75	2-15/16"	162	31	398
HOP-76	76	3"	162	31	398
HOP-80	80	3-1/8"	171	35	403
HOP-85	85	3-3/8"	178	36	428
HOP-90	90	3-5/8"	194	38	453
HOP-95	95	3-3/4"	194	38	453

Ring Spanner

Part No	Spanner Size A/F		Ring Type		
	MM	Inch	Head Dia	Head Depth	Length
HRS-32	32	1-1/4"	65	21	207
HRS-33	33	1-5/16"	65	21	207
HRS-35	35	1-3/8"	65	21	207
HRS-36	36	1-7/16"	65	21	207
HRS-38	38	1-1/2"	65	21	207
HRS-41	41	1-5/8"	78	26	240
HRS-43	43	1-11/16"	78	26	240
HRS-44	44	1-3/4"	78	26	240
HRS-46	46	1-13/16"	78	26	240
HRS-47	47	1-7/8"	78	26	240
HRS-50	50	2"	78	26	240
HRS-52	52	2-1/16"	100	33	283
HRS-55	55	2-3/16"	100	33	283
HRS-57	57	2-1/4"	100	33	283
HRS-60	60	2-3/8"	100	33	283
HRS-62	62	2-7/16"	100	33	283
HRS-63	63	2-1/2"	100	33	283
HRS-65	65	2-9/16"	100	33	283
HRS-67	67	2-5/8"	120	38	320
HRS-70	70	2-3/4"	120	38	320
HRS-71	71	2-13/16"	120	38	320
HRS-75	75	2-15/16"	120	38	320
HRS-76	76	3"	120	38	320
HRS-80	80	3-1/8"	120	38	320
HRS-85	85	3-3/8"	127	38	338
HRS-90	90	3-5/8"	133	43	348
HRS-95	95	3-3/4"	138	43	372
HRS-98	98	3-7/8"	154	48	413
HRS-100	100	4"	154	48	413
HRS-105	105	4-1/8"	160	48	448
HRS-110	110	4-3/8"	168	53	448
HRS-115	115	4-1/2"	172	53	463
HRS-120	120	4-3/4"	172	58	488
HRS-125	125	4-7/8"	198	58	508
HRS-130	130	5"	208	63	513

Offset Handle Type Spanner

Part No	Spanner Size A/F		Offset Handle Type		
	MM	Inch	Head Dia	Head Depth	Length
HOF-32	32	1-1/4"	54	23	263
HOFF-33	33	1-5/16"	56	24	268
HOFF-35	35	1-3/8"	57	24	268
HOFF-36	36	1-7/16"	61	26	288
HOFF-38	38	1-1/2"	65	26	288
HOFF-41	41	1-5/8"	67	26	288
HOFF-43	43	1-11/16"	67	26	288
HOFF-44	44	1-3/4"	67	26	288
HOFF-46	46	1-13/16"	75	30	338
HOFF-47	47	1-7/8"	75	34	338
HOFF-50	50	2"	81	35	338
HOFF-52	52	2-1/16"	84	37	358
HOF -55	55	2-3/16"	89	37	358
HOFF-57	57	2-1/4"	89	37	358
HOFF-60	60	2-3/8"	95	40	378
HOFF-62	62	2-7/16"	98	42	378
HOFF-63	63	2-1/2"	100	42	378
HOFF-65	65	2-9/16"	103	42	378
HOFF-67	67	2-5/8"	106	42	378
HOFF-70	70	2-3/4"	110	46	398
HOFF-71	71	2-13/16"	110	48	398
HOFF-75	75	2-15/16"	118	48	398
HOF -76	76	3"	120	48	398
HOF -80	80	3-1/8"	124	58	434
HOFF-85	85	3-3/8"	130	58	434
HOFF-90	90	3-5/8"	140	58	438
HOFF-95	95	3-3/4"	148	58	463
HOFF-98	98	3-7/8"	156	58	463
HOFF-100	100	4"	162	58	463
HOFF-105	105	4-1/8"	170	63	538
HOFF-110	110	4-3/8"	178	63	538
HOFF-115	115	4-1/2"	184	63	538
HOFF-120	120	4-3/4"	192	68	538
HOFF-125	125	4-7/8"	198	68	538
HOFF-130	130	5"	203	68	538